


2.2. Wind Rose: Graphical Presentation of joined wind speed and direction (Top Anemometer 33W) (North = 0 Deg ; South = 180 Deg ; West = 270 Deg ; East = 90 Deg)



2.3 Graphical Presentation of wind speed frequency distribution (Top Anemometer _33 W)

